

# The Churchi I I

## Chest Clip Guard

---

### WARNING:

The Chest Clip Guard may present a strangulation hazard if your child:

- is extremely flexible and does not remain in a normal seated position (such as turning their torso around at least 90 degrees),
- unbuckles the crotch buckle,
- or if an occupant of the vehicle pulls up on the neck strap.

NEVER LEAVE YOUR CHILD UNATTENDED!

Merri tt Manufacturing

## Important Warnings and Notes

### WARNING:

The Chest Clip Guard may present a strangulation hazard if your child:

- is extremely flexible and does not remain in a normal seated position (such as turning their torso around at least 90 degrees),
- unbuckles the crotch buckle,
- or if an occupant of the vehicle pulls up on the neck strap.

**NEVER LEAVE YOUR CHILD UNATTENDED!**


NOTE: This Chest Clip Guard is designed to help prevent the occupant from escaping the Churchill.

NOTE: This Chest Clip Guard replaces the standard chest clip. One of them must be used at all times.

NOTE: Two plastic keys are provided for opening the Chest Clip Guard. We recommend that you attach them on two separate key rings. Additional keys can be ordered from Merritt Manufacturing at 317-409-0148.

NOTE: In the event of an emergency, any key can be used to unlock the Chest Clip Guard. However, for longest life of the lock, always use the plastic key provided.

## Parts



## Fitting the Chest Clip Guard to the Occupant

1. Position the Chest Clip Guard on a flat surface with the front side facing up, as shown in Figure A.
2. Verify that the strap is adjusted to its longest length, by pulling with both hands as shown in Figure B.



NOTE: The web adjusters (Figure C) on the Chest Clip Guard **are shipped “unlocked”**. However, if the strap will not pull out to its longest length, then verify that each web adjuster is unlocked, by turning its set screw counter clockwise with **the 3/16” allen wrench** provided, (Figure D).



NOTE: After the Chest Clip Guard is pulled out to **its longest length** (Figure B), proceed to Step 3 on the following page.



## Fitting the Chest Clip Guard to the Occupant, Cont.

**NOTE: The “Chest Clip Part” is a part of the Chest Clip Guard.** The chest clip is what you will be removing from the Churchill on Page 7.

NOTE: The Chest Clip Guard features a lock (Figure E) that prevents the occupant from opening the chest clip part of the Chest Clip Guard. The Chest Clip Guard is shipped **“unlocked”**.

However, if it will not open, unlock it by inserting the white plastic key provided into the key hole in the center of the chest clip part and turn it clockwise until you hear a click (Figure E).


3. Open the Chest Clip guard (Figures F and G).
4. Place the Chest Clip Guard over the back of the occupant's neck, allowing it to hang over his/her chest (Figure H).



## Fitting the Chest Clip Guard to the Occupant, Cont.

5. Close the Chest Clip Guard (Figure I).
6. While holding the chest clip part with one hand, pull the loose end of each strap (Figure J) until the chest clip part is positioned level with **the occupant's arm pits** or higher (Figure K).

NOTE: Try to keep the lengths of the loose ends even (Figure K).



7. Remove the Chest Clip Guard (Figures L and M) from the occupant and place it on a flat surface (Figure N).
8. Tighten each web adjuster, by turning its set screw clockwise **with the 3/16” allen wrench** provided, so that the desired strap length is locked in place (Figure N).



## Installation of the Chest Clip Guard

1. From below the Chest Clip Guard, insert one of the harness straps through its corresponding sleeve **through it's** corresponding sleeve (Figure A).
2. Then pull the harness strap out of the top of the sleeve (Figure B).
3. Attached the anchor to the support harness (Figures C and D).







## Installation of the Chest Clip Guard, Cont.

4. Repeat Steps 4 and 5 for the other harness strap.



## Installation of Occupant with Chest Clip Guard

1. Secure your child in the restraint according to the **“Instructions for Use” Manual, allowing the strap to go around the back of your child’s neck** (Figure A).
2. Close the Chest Clip Guard (Figures B and C).
3. To lock the Chest Clip Guard, insert the white plastic key provided into the key hole in the center of the Chest Clip Guard and turn it clockwise until you hear a click (Figure D).
4. Verify that the Chest Clip Guard is locked by trying to manually open it (Figure E).



## Installation of Occupant with Chest Clip Guard, Cont.

5. Continue to secure your child in the restraint according to the Churchill **“Instructions for Use”** Manual (Figures F,G, H).



### Unlocking the Chest Clip Guard

1. To unlock the Chest Clip Guard, insert the white plastic key provided into the key hole in the center of the Chest Clip Guard and turn it clockwise until you hear a click (Figure I).



**NOTE:**  
Removal of occupant is the opposite of installation.

**NOTE:** In the event of an emergency, any key can be used to unlock the Chest Clip Guard. However, for longest life of the lock, always use the plastic key provided.

**NOTE:** Two plastic keys are provided for opening the Chest Clip Guard. We recommend that you attach them on two separate key rings. Additional keys can be ordered from Merritt Manufacturing at 317-409-0148

## Limited Warranty

Merritt Manufacturing, Inc. (Merritt) provides the following limited warranty on the Churchill:

Merritt warrants to the original purchaser of the Churchill that, if properly used strictly in accordance with the instructions and specifications included in the original packaging, it shall be free from defects in materials or workmanship for a period of one (1) year from the date of original purchase. Proof of purchase is required, including, but not limited to furnishing to Merritt proof that the owner registration card was returned to Merritt within thirty days of the original purchase or furnishing to Merritt proof of purchase that identifies the claimant as the original purchaser. If any component covered by this warranty fails for reasons covered by this warranty, Merritt will, at its option, provide the original purchaser with repair or replacement components for the covered product or component. This limited warranty is available only for purchasers in the United States and Canada. Merritt reserves the right to discontinue or change fabrics, parts, models or products, or to make substitutions. Please note that the upholstery fabric is subject to some degree of wear as a result of normal use. This kind of normal wear is not covered under warranty.

To make a claim under this warranty, you must contact Merritt via telephone at (317) 409-0148 or write to the company using the address on the back cover of this booklet. PLEASE COMPLETE AND MAIL THE OWNER REGISTRATION CARD WITHIN THIRTY DAYS OF PURCHASE TO PRESERVE YOUR WARRANTY RIGHTS.

### WARRANTY LIMITATIONS

This warranty does not include damages due to external sources, including, but not limited to accident, negligence, misuse, neglect, alteration, repair, improper installation, improper testing or use that is not in conformance with the instructions and specifications in the instruction booklet.

### LIMITATION OF LIABILITY AND DAMAGES

THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE THE SOLE AND EXCLUSIVE REMEDIES AND ARE PROVIDED IN LIEU OF ALL OTHERS, ORAL OR WRITTEN, EXPRESS OR IMPLIED. IN NO EVENT WILL MERRITT, OR THE RETAILER/DISTRIBUTOR SELLING THIS PRODUCT, BE LIABLE TO THE PURCHASER, OR ANY USER OF THIS RESTRAINT OR OTHER THIRD PARTY, FOR ANY DAMAGES; INCLUDING LOST PROFITS, LOST BUSINESS, INCIDENTAL, INDIRECT, SPECIAL, CONSEQUENTIAL DAMAGES OR PUNITIVE DAMAGES. IN NO EVENT SHALL MERRITT OR ITS AFFILIATED COMPANIES BE LIABLE OR RESPONSIBLE FOR ANY

## Limited Warranty, Continued

AMOUNT OF DAMAGES ABOVE THE AGGREGATE DOLLAR AMOUNT PAID BY THE CUSTOMER FOR THE PURCHASE OF THE PRODUCT COVERED BY THIS WARRANTY.

### LIMITATIONS OF WARRANTIES AND OTHER WARRANTY TERMS AND STATES' LAW

MERRITT FULLY DISCLAIMS AND MAKES NO IMPLIED WARRANTIES OF ANY KIND, INCLUDING, BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR USE, AND MAKES NO EXPRESS WARRANTIES BEYOND THOSE STATED HERE. NOTWITHSTANDING THE FOREGOING, IF ANY IMPLIED WARRANTIES ARE DEEMED TO BE GIVEN BECAUSE THE APPLICABLE LAW PROHIBITS THEIR EXCLUSION, THEN ANY SUCH IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION AND TERMS OF THE EXPRESS WRITTEN WARRANTY. SOME STATES DO NOT ALLOW THE LIMITATION OF IMPLIED WARRANTIES, LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. THEREFORE, IN THOSE STATES, THE LIMITATIONS LISTED ABOVE MAY NOT APPLY TO YOU. THIS WARRANTY AFFORDS YOU WITH SPECIFIC LEGAL RIGHTS AND YOU MAY HAVE ADDITIONAL RIGHTS, DEPENDING ON THE STATE IN WHICH YOU RESIDE.

### BINDING ARBITRATION

Any dispute, controversy or claim (whether in contract, tort or otherwise, whether pre-existing, present or future, and including statutory, common law, intentional torts and equitable claims) against Merritt, its agents, employees, successors, assigns or affiliates (collectively for purposes of this warranty, "Merritt"), arising from or relating to this warranty and agreement, its interpretation, or the breach, termination or validity thereof, the relationships which result from this warranty and agreement (including, to the full extent permitted by applicable law, relationships with third parties who are not parties to this warranty and agreement), SHALL BE RESOLVED EXCLUSIVELY AND FINALLY BY BINDING ARBITRATION ADMINISTERED BY THE AMERICAN ARBITRATION ASSOCIATION under its code of procedure then in effect. Any award of the arbitrator shall be final and binding on each of the parties and may be entered as a judgment in any court of competent jurisdiction. Information for submitting claims with the American Arbitration Association may be obtained at [www.adr.org](http://www.adr.org).

**Page**  
**Intentionally**  
**Left**  
**Blank**

**Page**  
**Intentionally**  
**Left**  
**Blank**

# The Churchill Chest Clip Guard

Merritt Manufacturing, Inc.  
P.O. Box 17152  
Indianapolis, IN 46217-0152  
USA

Phone: 317-409-0148  
Fax: 317-893-2567  
[www.merrittcarseat.com](http://www.merrittcarseat.com)  
E-Mail: [info@merrittcarseat.com](mailto:info@merrittcarseat.com)

The Churchill Chest Clip Guard Installation  
Instructions, Revision 0